



FITTING AND INSTALLATION INSTRUCTION PIPEMATE DISMANTLING JOINT



Pipemate Dismantling Joint has been developed to provide flexibility in flanged pipework system at the design and installation stages.

This dismantling joint eliminates the need for more complex anchoring systems and is excellent method of providing a demountable joint in an otherwise flanged pipework systems.



PIPEMATE SDN BHD (106977-A)

No.28, (Lot 17512), Jalan Dua, Kawasan Perindustrian Selayang,
Taman Selayang Baru, 68100 Selangor Darul Ehsan, Malaysia.
Tel: 603-61380977, 61388667 Fax: 603-61388772
email : pipemate@tm.net.my, pipemate@streamyx.com